Maintenance schedule 0229 - F 800 GS, K72

00 00 111 BMW Service		
Reading fault memory with BMW Motorrad diagnostic system		
11 00 611 Oil change, engine, with filter	Annually or every 10,000 km	
11 34 502 Checking valve clearance (for maintenance)	Every 20,000 km	
12 12 509 Replace all spark plugs (as part of maintenance)	Every 40,000 km	
13 72 505 Replace air filter cartridge (for maintenance)	Every 20,000 km	
31 42 899 Oil change in telescopic front forks	Every 30,000 km	
Checking coolant level		
Check/adjust clutch play		
Checking front brake pads and brake discs for wear		
Checking rear brake pads and brake disc for wear		
Checking brake fluid level, front and rear		
Visually inspecting brake pipes, brake hoses and connections		
Checking spoke tension, adjusting if necessary		
Checking tire pressures and tread depth		
Checking and lubricating chain drive		
Checking ease of movement of side stand		
Check the steering-head bearing		
Final inspection and check of roadworthiness		
Reading fault memory with BMW Motorrad diagnostic system		
Setting service-due date and service countdown distance		
Checking battery charge state		
Confirming BMW Service in on-board documentation		