Maintenance schedule

0187 - F 650 CS

00 00 125 BMW Service with Annual Inspection (see Maintenance Schedule) (annually, initially at 10,000 km, then every 20,000 km)

Reading fault-code memories with the BMW Motorrad diagnostic system		☐
Changing engine oil (engine and oil tank) and oil filter element		☐
11 41 540 Cleaning oil strainer (without draining/topping up engine oil) ***)**	**once only at 10,000 km**	☐
Greasing rubber grommets for cover insert		☐
Checking coolant level		☐
17 00 505 Change coolant in system (maintenance) ***)**	**every four years**	☐
Checking valve clearance		☐
Replacing spark plugs	**initially at 30,000 km, then every 20,000 km**	☐
Draining intake air silencer		☐
Checking battery acid level		☐
Cleaning and greasing battery terminals		☐
Checking clutch play		☐
Checking front brake fluid level		☐
Checking brake-fluid level, rear brake		☐
Checking front brake pads for wear		☐
Checking front brake disc for wear		☐
Checking rear brake pads for wear		☐
Checking rear brake disc for wear		☐
34 00 548 Changing brake fluid, front brakes ***)**	**every two years**	☐
34 00 549 Changing brake fluid, rear brakes ***)**	**every two years**	☐
Checking toothed belt		☐
Checking belt tension		☐
Checking steering head bearing play		☐

Checking operation of side-stand switch	☐
Lubricating side stand	☐
Checking specified torque of threaded fasteners with torque wrench: engine / engine carrier / frame and cylinder head / main frame	☐
Checking specified torque of threaded fasteners with torque wrench: main frame and rear frame	☐
Checking specified torque of threaded fasteners with torque wrench: eccentric clamp	☐
Checking specified torque of threaded fasteners with torque wrench: exhaust system	☐
Checking tyre pressures and tread depth	☐
Checking lights and signalling equipment	☐
Final inspection and function check	☐
Confirming BMW Service in on-board documentation	☐

***) Billed as a separate item**

☐ **not as per the normal schedule**

06.06.06