Maintenance schedule

0185 - F 650 GS

00 00 131 BMW Inspection with Annual Inspection (see Maintenance Schedule) (annually, every 20,000 km)

Equipment trim-level variant:
0524 - Anti-lock braking system (ABS)

Reading fault-code memories with the BMW Motorrad diagnostic system		☐
Changing engine oil (engine and oil tank) and oil filter element		☐
Checking coolant level		☐
17 00 505 Change coolant in system (maintenance) ***)**	**every four years**	☐
Checking valve clearance		☐
Emptying drain hose from intake air silencer		☐
Replacing air filter element		☐
16 12 525 Replace the fuel filter (during maintenance) ***)**	**every 40,000 km**	☐
Checking clutch play		☐
Checking spoke tension, adjusting if necessary		☐
Checking front brake pads for wear		☐
Checking front brake disc for wear		☐
Checking rear brake pads for wear		☐
Checking rear brake disc for wear		☐
Checking front brake fluid level		☐
Checking brake-fluid level, rear brake		☐
Testing brake system and checking for leaks		☐
32 72 510 Installing repair kit, piston for handbrake fitting (without bleeding) ***)**	**every 40,000 km**	☐
34 31 536 Installing piston repair kit in footbrake cylinder (without bleeding) ***)**	**every 40,000 km**	☐
34 00 548 Changing brake fluid, front brakes ***)**	**every two years**	☐
Changing brake fluid, rear brakes		☐
Checking chain, chain sprocket and chain pinion		☐

Checking chain takeup roller and slider rail	☐
Checking chain tension	☐
Checking battery acid level	☐
Cleaning and greasing battery terminals	☐
Checking steering head bearing play	☐
Checking operation of side-stand switch	☐
Lubricating side stand	☐
Lubricating centre stand	☐
Lubricating footbrake lever	☐
Checking specified torque of threaded fasteners with torque wrench: engine / main frame, engine / engine carrier and cylinder head / main frame	☐
Checking specified torque of threaded fasteners with torque wrench: main frame / rear frame, frame bottom section / main frame and engine carrier / main frame	☐
Checking specified torque of threaded fasteners with torque wrench: footrest plate / main frame and centre stand / main frame	☐
Checking specified torque of threaded fasteners with torque wrench: exhaust system	☐
Checking tyre pressures and tread depth	☐
Checking lights and signalling equipment	☐
Final inspection and function check	☐
Confirming BMW Service in on-board documentation	☐

***) Billed as a separate item**

☐ **not as per the normal schedule**