

Maintenance schedule

0539 - K 1300 GT, K44 31

Reading fault memory with BMW Motorrad diagnostic system		<input type="checkbox"/>
11 00 609 Oil change in engine with filter (for maintenance)	Annually or every 10,000 km	<input type="checkbox"/>
11 34 502 Checking valve clearance (for maintenance)	Every 30,000 km	<input type="checkbox"/>
12 12 509 Replace all spark plugs (as part of maintenance)	Every 30,000 km	<input type="checkbox"/>
13 72 505 Replace air filter cartridge (for maintenance)	Every 20,000 km	<input type="checkbox"/>
33 00 501 Oil change, rear wheel drive	Every two years or every 20,000 km	<input type="checkbox"/>
Visually inspecting brake pipes, brake hoses and connections		<input type="checkbox"/>
Checking front brake pads and brake discs for wear		<input type="checkbox"/>
Checking brake-fluid level, front brakes		<input type="checkbox"/>
Checking rear brake pads and brake disc for wear		<input type="checkbox"/>
Checking brake-fluid level, rear brakes		<input type="checkbox"/>
Checking clutch system		<input type="checkbox"/>
Checking play of throttle cable		<input type="checkbox"/>
Checking coolant level		<input type="checkbox"/>
Checking tire pressures and tread depth		<input type="checkbox"/>
Checking ease of movement of side stand		<input type="checkbox"/>
Checking ease of movement of center stand		<input type="checkbox"/>
Checking lights and signaling equipment		<input type="checkbox"/>
Function test, engine start suppression		<input type="checkbox"/>
18 21 510 Lubricating ball-joint clamp (for maintenance)	every 20,000 km	<input type="checkbox"/>
Final inspection and check of roadworthiness		<input type="checkbox"/>
Reading fault memory with BMW Motorrad diagnostic system		<input type="checkbox"/>
Setting service-due date and service countdown distance		<input type="checkbox"/>
Check the battery charge state		<input type="checkbox"/>
Confirming BMW Service in on-board documentation		<input type="checkbox"/>