

Maintenance schedule

0534 - S 1000 RR, K46 11

00 00 111 BMW Service

Performing vehicle test with BMW Motorrad diagnostic system		<input type="checkbox"/>
11 00 609 Oil change in engine with filter (for maintenance)	Annually or every 10,000 km	<input type="checkbox"/>
11 34 502 Checking valve clearance (for maintenance)	Every 30,000 km	<input type="checkbox"/>
11 30 502 Checking valve timing (cylinder head cover removed)	Every 30,000 km	<input type="checkbox"/>
12 12 509 Replace all spark plugs (as part of maintenance)	Every 30,000 km	<input type="checkbox"/>
13 72 505 Replace air filter cartridge (for maintenance)	Every 10,000 km	<input type="checkbox"/>
31 42 902 Changing fluid in telescopic forks (for maintenance)	Every 30,000 km	<input type="checkbox"/>
Visually inspect the brake pipes, brake hoses and connections		<input type="checkbox"/>
Checking front brake pads and brake discs for wear		<input type="checkbox"/>
34 00 548 Changing brake fluid, front brakes	Initially after one year, then every two years	<input type="checkbox"/>
Checking rear brake pads and brake disc for wear		<input type="checkbox"/>
34 00 549 Changing brake fluid, rear brakes	Initially after one year, then every two years	<input type="checkbox"/>
Checking steering-head bearing		<input type="checkbox"/>
Checking coolant level		<input type="checkbox"/>
Checking play of throttle cable		<input type="checkbox"/>
Checking fastener of clutch lever fitting		<input type="checkbox"/>
Checking clutch cable and clutch-lever play		<input type="checkbox"/>
Lubricating clutch mechanism		<input type="checkbox"/>
Checking drive chain, sprocket and pinion		<input type="checkbox"/>
Checking tire pressures and tread depth		<input type="checkbox"/>

- | | |
|--|--------------------------|
| Checking ease of movement of side stand | <input type="checkbox"/> |
| Lubricating side stand | <input type="checkbox"/> |
| Check the lights and signaling equipment | <input type="checkbox"/> |
| Function test, engine start suppression | <input type="checkbox"/> |
| Final inspection and check of roadworthiness | <input type="checkbox"/> |
| Performing vehicle test with BMW Motorrad diagnostic system | <input type="checkbox"/> |
| Setting service-due date and service countdown distance | <input type="checkbox"/> |
| Checking battery charge state | <input type="checkbox"/> |
| Confirming BMW Service in on-board documentation | <input type="checkbox"/> |