

# Maintenance schedule

## 0559 - K 1200 LT

00 00 128 BMW Inspection (see Maintenance Schedule) (every 20,000 km)

Equipment trim-level variant:  
0538 - Cruise-control system

Checking battery charge state		<input type="checkbox"/>
Reading out fault memory		<input type="checkbox"/>
Performing bleed test with the BMW Motorrad diagnostic system		<input type="checkbox"/>
Checking play of throttle actuator cable		<input type="checkbox"/>
32 73 514 Additional work, checking throttle cable, cruise-control system (for maintenance) *)		<input type="checkbox"/>
Engine-oil change, with filter		<input type="checkbox"/>
23 00 510 Gearbox-oil change (maintenance) *)	every two years or every 40,000 km	<input checked="" type="checkbox"/>
33 00 501 Oil change, rear wheel drive *)	every two years or every 40,000 km	<input checked="" type="checkbox"/>
Checking front brake pads for wear		<input type="checkbox"/>
Checking front brake discs for wear		<input type="checkbox"/>
Checking rear brake pads for wear		<input type="checkbox"/>
Checking rear brake disc for wear		<input type="checkbox"/>
Checking front brake fluid level		<input type="checkbox"/>
Checking brake-fluid level, rear brake		<input type="checkbox"/>
Visual inspection of the brake pipes, brake hoses and connections		<input type="checkbox"/>
Checking clutch operating fluid level		<input type="checkbox"/>
Replacing intake air filter element		<input type="checkbox"/>
16 12 501 Replace fuel filter (trim panels removed) *)	every 40,000 km	<input checked="" type="checkbox"/>
Checking coolant level and concentration		<input type="checkbox"/>
Lubricating side-stand pivot mounts		<input type="checkbox"/>
Checking centre-stand pivot mounts		<input type="checkbox"/>
Checking steering damper		<input type="checkbox"/>
Checking rear wheel bearing play by tilting wheel		<input type="checkbox"/>

Checking swinging arm bearing for play	<input type="checkbox"/>
Checking valve clearance	<input type="checkbox"/>
11 31 705 Additional work: Replace liner on chain tensioning rail, slide rail and thrust block (fuel tank / cylinder head cover removed) *)	every 60,000 km <input checked="" type="checkbox"/>
Changing spark plugs	<input type="checkbox"/>
Function test, engine start suppression	<input type="checkbox"/>
Checking condition of tyres and wheels and checking tyre pressures	<input type="checkbox"/>
Checking lights and signalling equipment	<input type="checkbox"/>
Test ride as final inspection and function check	<input type="checkbox"/>
Confirming BMW Service in on-board documentation	<input type="checkbox"/>

\*) Billed as a separate item

not as per the normal schedule