

Maintenance schedule

0597 - K 1200 GT

00 00 125 BMW Service with Annual Inspection (see Maintenance Schedule) (Annually, initially at 10,000 km, then every 20,000 km)

Reading fault memory with BMW Motorrad diagnostic system		<input type="checkbox"/>
Oil change in engine and oil tank, with filter		<input type="checkbox"/>
33 00 501 Oil change, rear wheel drive *)	Every two years or every 20,000 km	<input type="checkbox"/>
11 34 502 Checking valve clearance (for maintenance) *)	Every 30,000 km	<input type="checkbox"/>
12 12 509 Replace all spark plugs (as part of maintenance) *)	Every 30,000 km	<input type="checkbox"/>
34 00 616 Changing brake fluid in Integral ABS wheel circuit, front (as part of maintenance) *)	Initially after one year, then every two years	<input type="checkbox"/>
34 00 617 Changing brake fluid in Integral ABS wheel circuit, rear (as part of maintenance) *)	Initially after one year, then every two years	<input type="checkbox"/>
34 00 608 Additional work for ABS: change brake fluid in entire ABS control circuit (for maintenance) *)	Initially after one year, then every four years	<input type="checkbox"/>
Checking freedom of movement of throttle cable and checking for kinks and chafing		<input type="checkbox"/>
Checking coolant level		<input type="checkbox"/>
Checking tire pressures and tread depth		<input type="checkbox"/>
Checking ease of movement of side stand		<input type="checkbox"/>
Checking ease of movement of center stand		<input type="checkbox"/>
Checking lights and signaling equipment		<input type="checkbox"/>
Function test, engine start suppression		<input type="checkbox"/>
Brake check for BMW Motorrad Integral ABS		<input type="checkbox"/>
Final inspection and check of roadworthiness		<input type="checkbox"/>
Reading fault memory with BMW Motorrad diagnostic system		<input type="checkbox"/>
Checking battery charge state		<input type="checkbox"/>
Confirming BMW Service in on-board documentation		<input type="checkbox"/>