

Maintenance schedule

0495 - R 1150 GS

00 00 128 BMW Inspection (see Maintenance Schedule) (every 20,000 km)

Equipment trim-level variant:

0645 - Integral ABS (partially integral)

| | | |
|--|------------------------------------|--------------------------|
| Reading fault-code memories with the BMW Motorrad diagnostic system | | <input type="checkbox"/> |
| Performing bleed test with the BMW Motorrad diagnostic system | | <input type="checkbox"/> |
| Changing engine oil with engine at operating temperature, replacing oil filter | | <input type="checkbox"/> |
| Changing oil in gearbox, warmed to normal operating temperature | | <input type="checkbox"/> |
| 33 00 501 Oil change, rear wheel drive *) | every two years or every 40,000 km | <input type="checkbox"/> |
| 16 12 525 Replace the fuel filter (during maintenance) *) | every 40,000 km | <input type="checkbox"/> |
| Checking battery acid level | | <input type="checkbox"/> |
| Cleaning and greasing battery terminals | | <input type="checkbox"/> |
| Replacing intake air filter | | <input type="checkbox"/> |
| Checking front brake fluid level | | <input type="checkbox"/> |
| Checking brake-fluid level, rear brake | | <input type="checkbox"/> |
| Visual inspection of the brake pipes, brake hoses and connections | | <input type="checkbox"/> |
| Checking front brake pads for wear | | <input type="checkbox"/> |
| Checking front brake discs for wear | | <input type="checkbox"/> |
| Checking rear brake pads for wear | | <input type="checkbox"/> |
| Checking rear brake disc for wear | | <input type="checkbox"/> |
| Checking clutch fluid level | | <input type="checkbox"/> |
| Checking rear wheel bearing play by tilting wheel | | <input type="checkbox"/> |
| Checking swinging-arm pivot mount | | <input type="checkbox"/> |
| Checking operation of side-stand switch | | <input type="checkbox"/> |
| Greasing side stand pivot | | <input type="checkbox"/> |
| 12 31 657 Repleace belt for generator (as part of maintenance) *) | every 40,000 km | <input type="checkbox"/> |
| Replacing spark plugs | | <input type="checkbox"/> |

| | |
|---|--------------------------|
| Adjusting valve clearance | <input type="checkbox"/> |
| Checking freedom of movement of throttle cable and checking for kinks and chafing | <input type="checkbox"/> |
| Checking/adjusting synchronisation | <input type="checkbox"/> |
| Checking tyre pressures and tread depth | <input type="checkbox"/> |
| Checking spoke tension | <input type="checkbox"/> |
| Checking lights and signalling equipment | <input type="checkbox"/> |
| Test ride as final inspection and function check | <input type="checkbox"/> |
| Confirming BMW Service in on-board documentation | <input type="checkbox"/> |

*) Billed as a separate item

not as per the normal schedule