

Maintenance schedule

0418 - R 1100 RT

00 00 125 BMW Service with Annual Inspection (see Maintenance Schedule) (annually, initially at 10,000 km, then every 20,000 km)

Changing engine oil with engine at operating temperature, replacing oil filter	<input type="checkbox"/>
Changing oil in gearbox, warmed to normal operating temperature	<input type="checkbox"/>
Changing oil in final drive, warmed to normal operating temperature	<input type="checkbox"/>
Adjusting valve clearance	<input type="checkbox"/>
Checking condition of spark plugs	<input type="checkbox"/>
Checking battery acid level	<input type="checkbox"/>
Cleaning and greasing battery terminals	<input type="checkbox"/>
Checking freedom of movement of throttle cable and checking for kinks and chafing	<input type="checkbox"/>
Checking clutch play	<input type="checkbox"/>
Checking front brake pads for wear	<input type="checkbox"/>
Checking front brake discs for wear	<input type="checkbox"/>
Checking brake-fluid level, front brakes	<input type="checkbox"/>
Checking rear brake pads for wear	<input type="checkbox"/>
Checking rear brake disc for wear	<input type="checkbox"/>
Checking brake-fluid level, rear brake	<input type="checkbox"/>
Changing brake fluid, front brakes	<input type="checkbox"/>
Changing brake fluid, rear brakes	<input type="checkbox"/>
Checking swinging-arm pivot mount	<input type="checkbox"/>
Lubricating side stand	<input type="checkbox"/>
Lubricating nipple of clutch cable	<input type="checkbox"/>
Checking operation of side-stand switch	<input type="checkbox"/>
Checking idle speed	<input type="checkbox"/>

- | | |
|--|--------------------------|
| Checking/adjusting synchronisation | <input type="checkbox"/> |
| Checking throttle valves | <input type="checkbox"/> |
| Checking tyre pressures and tread depth | <input type="checkbox"/> |
| Checking lights and signalling equipment | <input type="checkbox"/> |
| Test ride as final inspection and function check | <input type="checkbox"/> |
| Confirming BMW Service in on-board documentation | <input type="checkbox"/> |