

Maintenance schedule

0398 - R 1200 R

00 00 128 BMW Inspection (see Maintenance Schedule) (every 20,000 km)

Equipment trim-level variant:

0636 - Centre stand

Reading fault memory with (BMW Motorrad) diagnostic system		<input type="checkbox"/>
Engine-oil change, with filter		<input type="checkbox"/>
23 00 510 Gearbox-oil change (maintenance *)	every two years or every 40,000 km	<input checked="" type="checkbox"/>
Adjusting valve clearance		<input type="checkbox"/>
12 12 509 Replace all spark plugs (as part of maintenance) *)	every 40,000 km	<input checked="" type="checkbox"/>
Replacing air filter element		<input type="checkbox"/>
12 31 657 Repleace belt for generator (as part of maintenance) *)	every 60,000 km	<input checked="" type="checkbox"/>
Visual inspection of hydraulic clutch system		<input type="checkbox"/>
Checking front brake discs for wear		<input type="checkbox"/>
Checking front brake pads for wear		<input type="checkbox"/>
Checking brake-fluid level, front brakes		<input type="checkbox"/>
Checking rear brake disc for wear		<input type="checkbox"/>
Checking rear brake pads for wear		<input type="checkbox"/>
Checking brake-fluid level, rear brakes		<input type="checkbox"/>
Checking freedom of movement of the throttle cable and checking for kinks and chafing		<input type="checkbox"/>
Checking tyre pressures and tread depth		<input type="checkbox"/>
Checking ease of movement of side stand		<input type="checkbox"/>
Checking ease of movement of centre stand		<input type="checkbox"/>
Checking lights and signalling equipment		<input type="checkbox"/>
Function test, engine start suppression		<input type="checkbox"/>
Checking synchronisation		<input type="checkbox"/>
Test ride as final inspection and function check		<input type="checkbox"/>
Reading fault memory with (BMW Motorrad) diagnostic system		<input type="checkbox"/>
Checking battery charge state		<input type="checkbox"/>
Confirming BMW Service in on-board documentation		<input type="checkbox"/>

*) Billed as a separate item

not as per the normal schedule